

07.1—137 Disassembly, cleaning, assembly and adjustment of injection nozzles

Job no. of flat rates or standard texts and flat rates data 07-6750 or 6752.

Testing data, injection nozzles

Bosch designation	Injection pressure in bar positive ¹⁾	
	for new injection nozzles	for old injection nozzles, min.
DNO SD 240 ²⁾ DNO SD 2400 DNO SD 240/ ³⁾	135—143	120

¹⁾ The difference between any two injection nozzles within one engine must not exceed 5 bar positive.

²⁾ Starting production code no. 928 or 041.

³⁾ Starting November 1981 with center hole 0.20 mm dia. (formerly 0.15 mm dia.)

Tightening torques

Nm

Injection nozzles, upper and lower parts

70—80


Special tools

Socket 27 mm, 1/2" drive



001 589 65 09 00

Cleaner



000 589 00 68 00

Conventional tools

Torque wrench 1/2" drive, 40—130 Nm

Tester EFEP 60 H

e.g. Bosch, D—7000 Stuttgart,
Order No. 0 681 200 502

Cleaning needles 0.13 mm dia.

e.g. Bosch, D—7000 Stuttgart,
Order No. KDEP 2900/3


Cleaning needles 0.18 mm dia.

e.g. Bosch, D—7000 Stuttgart
Order No. KDEP 2900/5

Note

The engine is equipped with a center hole pintle nozzle which is distinguished from the standard pintle by a cross hole and a center hole (14 and 15) in the thrust pin. Moreover, a maintenance-free edge filter (13) is pressed into upper part (7) of the injection nozzle holder.


- 1 Needle valve
- 2 Nozzle body
- 3 Nozzle holder insert
- 4 Thrust pin
- 5 Injection nozzle holder, lower part
- 6 Compression spring
- 7 Injection nozzle holder, upper part
- 8 Leak-off connection
- 9 Fuel inlet
- 10 Steel shim
- 11 Annular groove and inlet ports
- 12 Pressure chamber in nozzle body
- 13 Edge filter
- 14 Cross hole
- 15 Center hole



Disassembly

1 Clamp upper part (7) of injection holder in vise so that leak-off connections cannot be damaged.

2 Using socket, release and unscrew lower part (5) of injection nozzle holder.



- 5 Injection nozzle holder, lower part
- 7 Injection nozzle holder, upper part

3 Remove steel shim (10), compression spring (6), thrust pin (4), nozzle holder insert (3) and nozzle body (2) together with needle valve (1).

Attention:


When disassembling nozzle, be sure to keep nozzle body, needle valve and all other parts in correct order.

Cleaning

4 Using brass brush, remove carbon deposits from end face of nozzle body (2), chiefly around nozzle orifice.


Using surface plate, check nozzle holder insert (3) and nozzle body (2) for truth at both ends.

- | | |
|---------------------------------------|------------------------------------|
| 1 Needle valve | 9 Fuel inlet |
| 2 Nozzle body | 10 Steel shim |
| 3 Nozzle holder insert | 11 Annular groove and inlet ports |
| 4 Thrust pin | 12 Pressure chamber in nozzle body |
| 5 Injection nozzle holder, lower part | 13 Edge filter |
| 6 Compression spring | 14 Cross hole |
| 7 Injection nozzle holder, upper part | 15 Center hole |
| 8 Leak-off connection | |



5 Clean pressure chamber (5) in nozzle body using annular groove scraper.

- | | |
|--|--------------------|
| 1 Annular groove | 7 Nozzle orifice |
| 2 Nozzle body | 8 Injection pin |
| 3 Inlet port | 9 Throttle pin |
| 4 Needle valve | 10 Needle seat |
| 5 Pressure chamber | 11 Thrust shoulder |
| 6 Orifice of inlet ports in pressure chamber | 12 Needle stem |
| | 13 Thrust pin |




6 Clean nozzle needle seat in nozzle body with cleaning cutter. This job should be given special care, since usability of a nozzle depends to a high degree on a good nozzle needle seat.

Do not apply excessive pressure with cleaning cutter.

Clean center hole (15 in fig. item 4) with cleaning needle (0.13 mm dia. or 0.18 mm dia.).


7 Clean injection hole in nozzle orifice, using injection hole cleaner. As can be seen in the illustration, work **from inside to outside** and not vice versa (so that injection hole cleaner is guided correctly and not twisted).



8 Clean nozzle needle with brass brush.

- 1 Annular groove
- 2 Nozzle body
- 3 Inlet port
- 4 Needle valve
- 5 Pressure chamber
- 6 Orifice of inlet ports in pressure chamber


- 7 Nozzle orifice
- 8 Injection pin
- 9 Throttle pin
- 10 Needle valve seat
- 11 Pressure shoulder
- 12 Needle stem
- 13 Thrust pin



Checking the needle valve

9 Subject to sight-check. Used nozzles are to be sight-checked after cleaning. Check needle valve for indented or rough seat, and also for worn or damaged injection pins. Exchange any nozzle that is damaged.

10 Carry out test for freedom of movement. To do so, immerse needle valve and nozzle body in filtered diesel fuel, inserting needle valve into nozzle body. Hold nozzle body vertically and draw needle valve out by about one third. It must be able to slide back into its seat under its own weight. Exchange injection nozzle if necessary.




Assembly

11 Introduce all parts into lower part (5) of injection nozzle in reverse order and screw on upper part (7). Be sure to fit thrust pin (4) on needle valve (1) at end showing hole.




12 Clamp upper part (7) of injection nozzle in vise and torque lower part (5) to 70–80 Nm.



Checking

13 Check injection nozzles for satisfactory jet, rattling sound, injection pressure and leakage (07.1–135).



107-20857

Adjustment

14 In order to obtain correct injection pressure setting, it may be necessary to insert or remove steel shims (10) between compression spring (6) and upper part (7) of injection nozzle.

Inserting = **higher injection pressure**

Removing = **lower injection pressure**

These shims are available in thicknesses of 1.0 to 1.8 mm, in steps of 0.05 to 0.05 mm. Increasing the preloading by 0.05 mm increases the injection pressure by about 3.0 bar positive.

